

DSP3-700 Ambisonic Presets

Preset #	Preset Name	Sub Model Number	Sat Model Number	System Description
1	10HDR_LSR6	10HDR-AW	LSR6	Sub channel tuned for 10HDR-AW, left and right channels tuned for LSR6
2	10HDR_LSR8	10HDR-AW	LSR8	Sub channel tuned for 10HDR-AW, left and right channels tuned for LSR8
3	10HDR_6.5HD	10HDR-AW	6.5HD-AW	Sub channel tuned for 10HDR-AW, left and right channels tuned for 6.5HD-AW
4	11BP-IG_LSR6	S11BP-IG	LSR6	Sub channel tuned for S11BP-IG, left and right channels tuned for LSR6
5	11BP-IG_LSR8	S11BP-IG	LSR8	Sub channel tuned for S11BP-IG, left and right channels tuned for LSR8
6	12HDR_LSR6	12HDR-AW	LSR6	Sub channel tuned for 12HDR-AW, left and right channels tuned for LSR6
7	12HDR_LSR8	12HDR-AW	LSR8	Sub channel tuned for 12HDR-AW, left and right channels tuned for LSR8
8	12HDR_6.5HD	12HDR-AW	6.5HD-AW	Sub channel tuned for 12HDR-AW, left and right channels tuned for 6.5HD-AW
9	12HDR_6.5HD2	12HDR-AW	6.5HD2-AW	Sub channel tuned for 12HDR-AW, left and right channels tuned for 6.5HD2-AW
10	12HDR_26.5HD	12HDR-AW	26.5HD-WF	Sub channel tuned for 12HDR-AW, left and right channels tuned for 26.5HD-WF
11	12BP-IG_LSR6	12BP-IG	LSR6	Sub channel tuned for 12BP-IG, left and right channels tuned for LSR6
12	12BP-IG_LSR8	12BP-IG	LSR8	Sub channel tuned for 12BP-IG, left and right channels tuned for LSR8
13	12BP-IG_6.5HD	12BP-IG	6.5HD-AW	Sub channel tuned for 12BP-IG, left and right channels tuned for 6.5HD-AW
14	12BP-IG_6.5HD2	12BP-IG	6.5HD2-AW	Sub channel tuned for 12BP-IG, left and right channels tuned for 6.5HD2-AW
15	LSR6	None	LSR6	All three channels tuned for LSR6 (mono)
16	LSR8	None	LSR8	All three channels tuned for LSR8 (mono)
17	6.5HD	None	6.5HD-AW	All three channels tuned for 6.5HD-AW (mono)
18	6.5HD2	None	6.5HD2-AW	All three channels tuned for 6.5HD2-AW (mono)
19	10HDR6	10HDR-AW	None	All three channels tuned for 10HDR-AW (mono) for use with LSR6
20	10HDR8	10HDR-AW	None	All three channels tuned for 10HDR-AW (mono) for use with LSR8
21	10HDR65	10HDR-AW	None	All three channels tuned for 10HDR-AW (mono) for use with 6.5HD-AW/6.5HD2-AW
22	11BP-IG6	S11BP-IG	None	ALL three channels tuned for S11BP-IG (momo) for use with LSR6
23	11BP-IG8	S11BP-IG	None	ALL three channels tuned for S11BP-IG (momo) for use with LSR8
24	12HDR6	12HDR-AW	None	All three channels tuned for 12HDR-AW (mono) for use with LSR6
25	12HDR8	12HDR-AW	None	All three channels tuned for 12HDR-AW (mono) for use with LSR8
26	12HDR65	12HDR-AW	None	All three channels tuned for 12HDR-AW (mono) for use with 6.5HD-AW/6.5HD2-AW
27	12BP-IG6	12BP-IG	None	All three channels tuned for 12BP-IG (mono) for use with LSR6
28	12BP-IG8	12BP-IG	None	All three channels tuned for 12BP-IG (mono) for use with LSR8
29	12BP-IG65	12BP-IG	None	All three channels tuned for 12BP-IG (mono) for use with 6.5HD-AW/6.5HD2-AW
30	*6.5HDFR	None	6.5HD-AW	All three channels tuned for 6.5HD-AW Full Range : Left, Right, Mono